



1. Connect parts (Items 1-4) in the order shown in the diagram.
2. Place (Item 9) onto (Item 1) and attach it to the back of the overflow port,
3. (Item 10) is attached to the front of the overflow port, and the screw hole is aligned with the screw hole of (Item 1). Use (Item 11) to fix it;
4. Align (Item 14) with (Item 10), and then use a 2mm hex wrench (provided) to secure screw (Item 12).
5. Cut the 1 1/2" Schedule 40 pipes (Item 5 and Item 7) to the desired lengths to fit the tub.
6. Using the proper solvent cement, assemble the bath drain pipes and fittings (Items 4-8) -Adjust ball joint as needed.
7. Secure drain elbow (Item 8) and drain flange gasket (Item 15) under the tub by screwing in the strainer body (Item 16) through tub drain hole from inside the tub.
8. Install (Item 17) into (Item 16) and tighten (Item 18) to (Item 17)
9. Tighten all connections.