



NO CAULK PREFORMED DRAINS INSTALLATION GUIDE

1. Disassemble all parts of your new **Samuel Müller No Caulk Shower Drain**. Make sure both sides of the shower base opening are clean.
2. Apply approved sealant to underside of the flange before placing it into the shower base hole. Do not twist while inserting.
NOTE: Plumber's putty is not to be used on ABS drain bodies.
3. While holding the strainer body in place, place the rubber gasket over male threads of the strainer body, up against the underside of the shower base. Then place the friction washer against rubber gasket.
4. Thread the lock nut onto the male threads and tighten until flange is fully compressed against top of shower base. **NOTE:** *In colder weather applications, additional tightening may be necessary after sealant warms.*
5. Once full compression is confirmed, remove any excess sealant from the top and bottom of the drain.
6. Cut the drain pipe so that in its finished position, it will terminate $\frac{3}{4}$ " below the top of the no-caulk barrel flange. Then install your shower base into its final location per the manufacturer's recommendations.
7. Slide the rubber gasket over the pipe, positioning it so that the flat side is facing down.
8. After all drain connections have been completed and cured properly, clean shower base of any debris. Test all connections to ensure there are no leaks.
9. Install the shower strainer and give the shower base a final cleaning before use.

