



Your Samuel Mueller® Décor Vanity Top and Shower or Tub Wall Surround will retain its beauty for a lifetime. Review these instructions to see how easy it is to care for your Samuel Mueller® Décor products.

Normal Cleaning

- Wipe the surface with a damp cloth or sponge.
- For basic stains, clean with mild detergent or general purpose cleaner.

Removing Persistent Stains

- Scrub the surface in a circular motion using a mild detergent (such as 409®) and a wet, gray Scotch-Brite® pad.
- Follow the above step with a wet, white Scotch-Brite® pad, moving in a circular motion, to restore a uniform appearance.

Maintaining a Uniform Appearance

- Occasionally, scrub the entire surface of the product with a wet, white Scotch-Brite® pad and mild detergent.

Removing Scuff Marks and Minor Scratches

- To remove minor scuff marks, use a wet, gray Scotch-Brite® pad with a mild detergent, rubbing in a circular motion. Follow this with a wet, white Scotch-Brite® pad, moving in a circular motion.
- To remove minor scratches, use a 320 grit sandpaper to completely remove the scratch. Follow this with a wet, green Scotch-Brite® pad, moving in a circular motion around the area of the scratch. Use a wet, gray Scotch-Brite® pad, moving in a circular motion and follow this with a wet, white Scotch-Brite® pad, moving in a circular motion over the same area.

Tips to Avoid Damage

- Wipe away strong acids, such as those found in drain cleaners. Some of these acids, when left on the surface, may cause whitening which can be difficult to remove.

Note: Scotch-Brite® is a registered trademark of 3M and the green, gray, and white pads may be purchased at most specialty hardware or building supply stores. The household cleaner, 409®, is a registered trademark of the Clorox company.